Part No. **ALL40208**

Fuel Line Check Valve

ALL40208

Valve is placed in-line near the fuel cell to prevent fuel from free-flowing in the event of an accident that damages the fuel pump or fuel line. The suction action of the fuel pump overrides the internal spring which opens the valve allowing fuel to flow without restriction. Valve accepts -10 ORB style fittings.

Related Components:

ALL49838.....6AN to -10 ORB Fitting
ALL49843.....8AN to -10 ORB Fitting
ALL49848.....10AN to -10 ORB Fitting
ALL49853.....12AN to -10 ORB Fitting

ALL49843

REV031226

Allstar Performance 8300 Lane Dr., Watervliet, MI 49098
Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com