



Part No. ALL18600

Bump Steer Kit

Kit includes a 5/8"-18 x 3" bolt and 4 spacers (.100", .200", .300" and .500").



Bump Steer Spacers:

ALL18602..... .030"
ALL18603..... .060"
ALL18604..... .100"
ALL18605..... .200"
ALL18606..... .300"
ALL18607..... .400"
ALL18608..... .500"

Allstar Performance 8300 Lane Dr., Watervliet, MI 49098
Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com