



Part No. ALL64204-64209

## Shock And Pull Bar Covers

Neoprene covers help protect from rock damage and to keep components clean while preventing the competition from knowing your secrets. Hook-and-loop material allows easy cover removal for adjustments. 3" covers are often used for 2-1/2" and 3" coil-over shocks and small diameter upper links. 6" covers work well on 5" springs and pull bar applications.

Part No:	Description
----------	-------------

- |               |          |
|---------------|----------|
| ALL64204..... | 3" x 14" |
| ALL64205..... | 3" x 16" |
| ALL64206..... | 6" x 7"  |
| ALL64207..... | 6" x 14" |
| ALL64208..... | 6" x 16" |
| ALL64209..... | 6" x 20" |

