



Part No. ALL60026

90/10 Shock Brackets

Brackets weld to the chassis to mount a shock between the chassis and the differential to control "unloading" during deceleration of hard braking. 1/8" thick steel brackets fit 1-1/2" dia. tubing and have four 1/2" holes, spaced 1" apart. 1-pair.

