



**Part No. ALL17022  
ALL17022-1**

## Titanium Shock Stud Kit For Frame Boss And Spuds

Shock stud kits include four studs and nylon locking half nuts to mount shock to chassis or front axle. Studs have 1/2"-20 threads that thread directly into pre-threaded bungs.

<b>Part No.</b>	<b>Description</b>
ALL17022.....	Stud Kit For 1/2"-20 Threaded Bungs
ALL17022-1.....	Stud w/ Nut (Single) For 1/2"-20 Threaded Bung
ALL17048.....	Black Half Nuts 1/2"-20, 10-Pack



ALL17022