



Part No. ALL22119

Front Arch Support

Arch supports are required when installing Allstar front support kits. They add strength to suspension mounting area and create mounting points for shock brackets. Arches are constructed of 1-3/4", .095 wall, mild steel tubing, 24" wide at the mounting points and 16" tall but may be trimmed to fit many applications. Sold each.

