



Part No. **ALL96414**

Dial Indicator With Magnetic Base

Dial indicator with magnetic base is a necessity when degreasing a camshaft, checking crankshaft end play, deck heights, dome heights, transmission end play or ring and pinion backlash. Universal magnetic base may be mounted anywhere. Shockproof dial indicator has 1" of travel in .001" increments. Base and dial indicator may also be purchased separately.



ALL96414



ALL96415



ALL96416

Related Parts

ALL96415.....Dial Indicator Only

ALL96416.....Magnetic Base Only

Allstar Performance 8300 Lane Dr., Watervliet, MI 49098
Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com