

Clamp-On Trailing Arm Bracket

Universal bracket mounts coil-over eliminator and shock next to axle and mounts trailing arm 4-1/2" below axle center line, either inside or outside of bracket. Allows Limited Late Models and Modifieds to be changed from coil-over to coil-over eliminator and shock. Grade 5 hardware and Nyloc nuts included.

