



Distribution Block Mounting Bracket

ALL48038

Bracket provides a secure mount for ALL48037 distribution block allowing it to be mounted directly under the master cylinder providing access to the adjustable proportioning valve. Bracket mounting holes are on 3-1/4" centers to fit most popular master cylinders.



Allstar Performance 8300 Lane Dr., Watervliet, MI 49098
Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com