



Part No. ALL56360
ALL56361

Quick Adjust External Bump Stop

External bump stop allows adjustment of suspension travel separate from the coil-over unit. The detented adjuster nut can be turned on the rod end for quick engagement adjustment. Each half turn equals 1/16" eliminating the need for packer shims. Bump stop bolts to the outside of lower control arm and to an upper chassis location (may need to drill a hole or use a clamp on bracket). Fine tune vehicle set-up by adjusting the upper bushing plate. Includes built-in travel indicator and two yellow 75 durometer bushings. Will also accept bump springs with 5/8" I.D. retainers (not included).

Part No.	Description
ALL56361.....	Bump Stop w/ Bushings
ALL56360.....	Bump Stop w/o Bushings



Related Parts:

1" Bump Stop Packs

- ALL64329..... 40dr Brown
- ALL64332..... 50dr Green
- ALL64335..... 55dr Orange
- ALL64338..... 60dr Purple
- ALL64341..... 65dr Black
- ALL64346..... 75dr Yellow



Bump Spring Cups (Sold Each)

- ALL64356..... 1.160" Inside Step O.D.
- ALL64357..... 1.200" Inside Step O.D.
- ALL64358..... 1.280" Inside Step O.D.



REV082620

Allstar Performance 8300 Lane Dr., Watervliet, MI 49098
Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com