



**Part No.**     **ALL64195**  
                  **ALL64196**  
                  **ALL64197**

## Spring Spacers

Spring Spacers can be used with 2-1/2" coil-over springs or with coil-over kits and 5" adapter when extra spacing is needed. Spacers have a 3.5 O.D.

| <b>Part No.</b> | <b>Description</b> |
|-----------------|--------------------|
| ALL64195.....   | 1" Spacer          |
| ALL64196.....   | 2" Spacer          |
| ALL64197.....   | 3" Spacer          |



REV080122

**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**  
**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**